




Noistop[®] Steel & Wood

INSTALLATION GUIDE



Step 1

First the steel supports must be placed and potentially supported by a concrete foundation. The supports are to be placed with a laser distance of 202 cm.




Step 2

The bottom panel is lifted from the side and placed between the supports so that the flanges are fitted on the front of the supports. (Noistop Wood: The stonewool is sticking out at the bottom side).



Step 3

When the panel has been placed along the soil, it is mounted with stainless steel screws through the holes in both flanges – all holes should be used.



Step 4

Noistop Steel: When the panel has been mounted a joint strip is placed on the top of the panels noisy side in all its length, securing a close joint between the panels. (Noistop Wood: Top and bottom fits into each other, no joint strip necessary).



Step 5

Now the next panel is placed on top of the first panel and is mounted in the same way. (Tip: Place a 45cm high panel between 2 bigger ones for a nice visual effect.)



Step 6

When the top panel has been mounted, the roof top has to be mounted (Tip: Fixate the roof top on the top panel before installation). Then the installation is finished. It is important that there are no "gaps" in the joint between panel and soil.



ROCKWOOL Denmark A/S

Hovedgaden 501
DK-2640 Hedehusene
Tel: +45 4656 1616
www.noistop.rockwool.com

Shown material: Noistop Wood Elba brown.

The greatest possible care has been taken in designing and putting together this communication. However, ROCKWOOL cannot issue any warranty relating to the completeness and accuracy of the information gathered, processing of information, results of the calculations, advice, example constructions and other results. All calculations, advice, example constructions and other results are approximations or typical values and will not bind ROCKWOOL. Please also note that the performance of the product in a construction or system strongly depends on the parameters of such a construction or system, such as but not limited to local soil conditions, the quality of the installation and other components. All of these parameters fall outside the scope of influence of ROCKWOOL. As a consequence, no warranty can be provided by ROCKWOOL as regards the performance of the product. All rights are reserved. No part of this communication may be reproduced or published by means of print, photo print, microfilm or any other means without ROCKWOOL's prior written permission. The contents of this communication are subject to amendment without notification. Although every care was taken during the preparation of this communication, ROCKWOOL cannot accept liability whatsoever for errors in this communication, nor for their consequences.

Please contact ROCKWOOL Noistop® for additional information or questions at +45 4656 1616.