

MuteMat[®] Gym

Light Maintenance Guide

				and the same of a first state of the		
	EQUIPMENT	DETERGENT	DILUTE	COVERAGE	PADS & BRUSHES	
1694	Initial Cleaning	All Purpose Cleaner	25ml / 1L of Water	5 to 15 m²/L	Soft nylon brush	
	Neutral Cleaning	All Purpose Cleaner	40ml / 1L of Water	5 to 15 m² / L	Contact pad, purple pad, or soft nylon brush	
	Heavy Soil Cleaner	Floor Finish Stripper	10ml / 1L of Water	5 to 15 m ² / L	Contact pad, purple pad, or soft nylon brush	

www.iKoustic.com 01937 588226 Sales@ikoustic.com **iKoustic Limited,** Units 4 & 5, Erivan Park, Sandbeck Way, Wetherby, West Yorkshire, LS22 7DN





IMPORTANT MAINTENANCE TIPS

1. Use high powered vacuum to pick up dust.

2. For large areas, use a rotary floor scrubber.

3. Dilute the detergents with water per the manufacturers instructions; use higher concentrations for stubborn stains or hard to clean areas.

4. Rinse, wet vacuum or mop up any detergent residue when cleaning the floor.

5. For gum, use generic gum remover; however, any solvent-based product should be rinsed well with water to avoid damaging your surface.

6. DO NOT use an Auto Scrubber with a squeegee attachment. It tends to not pick up all of the dirty water solution and leaves a film of diluted dirty water on the tiles.

7. DO NOT use petroleum or citrus-based detergents.

Light Maintenance Guide

CLEANING INSTRUCTIONS

A – INITIAL CLEANING

- 1. Remove all surface soil, debris, sand and grit with a vacuum.
- 2. Scrub floor with a neutral detergent.

3. Pick up solution with a wet vacuum, rinse with clean water and allow to dry thoroughly.

4. This process may be done in one or two steps with a floor scrubber or SteamVac.

B – DAILY/REGULAR CLEANING

1. Sweep or vacuum floor to remove surface soil, debris, sand and grit.

2. Mop the floor with a damp mop.

3. This process may be done in one or two steps with a Floor Scrubber or SteamVac.

4. Allow floor to dry thoroughly.

C – INTERIM MAINTENANCE

1. Sweep or vacuum floor to remove surface soil, debris, sand and grit.

2. Mop the floor with a damp mop.

3. This process may be done in one or two steps with a Floor Scrubber or SteamVac.

4. Allow floor to dry thoroughly.

D – RESTORATIVE MAINTENANCE

- 1. Vacuum floor thoroughly.
- 2. Scrub using a rotary scrubber and Floor Finish Stripper.
- 3. Pick up solution with a wet/dry vacuum or SteamVac.
- 4. Allow floor to dry thoroughly.

EQUIPMENT	SPECIFICATIONS		
SteamVac Machine	Similar to any SteamVac model with scrubber and vacuum.		
Rotary Floor Scrubber	IbberRotary Floor Scrubber with a 33cm cleaning width is your best option to clean DuraSound. It works well in large areas and is especially manoeuvrable around equipment.		
Power Scrubber	43cm rotary floor buffer with mounted detergent tank and feed line to the brush. A circular brush attachment should be used.		
Wet/Dry Shop Vacuum	Power Unit: Minimum 1.7 hp commercial unit, 7.0 amp, 120 volt AC, 50/60 Hz two stage bypass motor. Tank Capacity: 45-60L, lined stainless steel or polypropylene. Accessories: Extension wand with a 15-30cm pickup nozzle, crevice tool & heavy duty extension cord.		
Detergent	Commercial/Industrial non-petroleum based neutral detergent: • Mr Muscle Floor Cleaner • Jantex Floor Finish Stripper		

EQUIPMENT SPECIFICATIONS



Wet Mop







Vacuum

Buffer

Steam Vac Floor Scrubber

www.iKoustic.com 01937 588226 Sales@ikoustic.com iKoustic Limited. Units 4 & 5, Erivan Park, Sandbeck Way, Wetherby, West Yorkshire, LS22 7DN

